

Camber Right $1/8 - 1/2$ degree positive

Left $1/2 - 3/4$ degree positive

Caster Right $3\frac{1}{2} - 5\frac{1}{2}$ degree positive

Left $3\frac{1}{4} - 5\frac{1}{4}$ degree positive

Toe $1/16$ " in

*Note – Camber offset needs to be $1/4 - 3/8$ degree, with the left side always higher than right
Caster offset needs to be $3/8 - 1/2$ degree, with the right side always higher than left