



INSTALLATION GUIDE



V-Nose Trailers

The Equal-i-zer® Hitch is one of the most versatile hitches for fitting a wide range of trailer frames. However, there are a few frame/trailer types that are more challenging for any type of hitch to be installed on.

The Equal-i-zer Hitch will work with most V-nose trailers, but it generally requires a modified installation method. The front of the trailer body on a V-nose trailer usually covers up the area on the A-frame where the Sway Control Brackets are installed. These brackets are optimal when mounted on the A-frame at 32" back from the center of the coupler to the center of the bracket (see Step 7 in our Installation Instructions at: <http://www.equalizerhitch.com/support/instructions.php>).

The positioning of the brackets can be moved forward up to 5" if there are objects in the way. This gives you a range from 27"-32" to mount the brackets. However, if the V-nose trailer body extends too far forward to mount the brackets in this range, you will need to consider further options. If this is the case, contact Customer Service at our toll-free phone line, or via e-mail, and we'll happily assist you.

Toll Free: 1 (800) 478-5578

Email: info@progressmfg.com