

These 3 valves are the (Hot) Water Heater bypass valves. Normal position is with the cold inlet and hot outlet valves OPEN and bypass valve CLOSED. Switch the position of all 3 valves to bypass the water heater for winterizing. Some RV's have a single combination cold water/bypass valve while some have a check valve in place of the hot water outlet valve, and some have both. See options #2 through 5 to the right.

