# SECTION 2 IDENTIFICATION AND SAFETY

## SAFETY REGULATIONS FOR LP

The following warnings are posted throughout your recreational vehicle to provide information on LP gas safety. They have been installed not only because of the requirement to do so, but also as a constant reminder to occupants of the recreational vehicle to exercise proper caution when using or being around LP gas appliances and equipment. We are listing them here so you may study them and be sure that you and your family understand and follow them.

# AWARNING

#### LP GAS CONTAINERS SHALL NOT BE PLACED OR STORED INSIDE THE LIVING AREA OF A RECREATIONAL VEHICLE. LP GAS CONTAINERS ARE EQUIPPED WITH SAFETY DEVICES WHICH RELIEVE EXCESSIVE PRESSURE BY DISCHARGING GAS INTO THE ATMOSPHERE.

# AWARNING

#### IT IS NOT SAFE TO USE COOKING APPLIANCES FOR COMFORT HEATING.

Cooking appliances need fresh air for safe operation. Before operation:

- 1. Open overhead vent or turn on exhaust fan, AND
- 2. Open a window

A warning label is located in the cooking area to remind you to provide an adequate supply of fresh air for combustion. Unlike homes, the amount of oxygen supply is limited due to the size of the recreational vehicle, and proper ventilation when using the cooking appliance(s) will avoid dangers of asphyxiation.

## DANGER

IT IS ESPECIALLY IMPORTANT THAT COOKING APPLIANCES **NOT** BE USED FOR COMFORT HEATING AS THE DANGER OF ASPHYXIATION and/or CARBON MONOXIDE POISONING IS GREATER WHEN THE APPLIANCE IS USED FOR PROLONGED PERIODS OF TIME.

WARNING DO NOT STORE LP GAS CONTAINERS, GASOLINE, OR OTHER FLAMMABLE LIQUIDS INSIDE THE VEHICLE AS A FIRE OR EXPLOSION MAY RESULT.

A WARNING LABEL HAS BEEN LOCATED NEAR THE LP GAS CONTAINER. This label reads: **Awarning DO NOT FILL CONTAINER(S) TO MORE THAN 80 PERCENT CAPACITY** 

Over-filling the LP gas container can result in uncontrolled gas flow which can cause fire or explosion. A properly filled container will contain approximately 80 percent of its' volume as liquid LP gas. An 80 percent automatic shut-off valve has been installed on the LP gas tank which will automatically prevent further filling when the gas volume has reached 80 percent of tank capacity.

The following label has been placed in the vehicle near the range area:

### **IF YOU SMELL GAS:**

- Extinguish any open flames, pilot lights and all smoking materials.
- DO NOT touch electrical switches.
- Shut off the gas supply at the tank valve(s) or gas supply connection.
- · Open doors and other ventilating openings.
- DO NOT USE THE RANGE HOOD.
- · Leave the area until the odor clears.
- Have the system checked and leakage source corrected before using again.