

SECTION 5

PLUMBING

To Empty the Holding Tanks

1. Remove the sewer drain hose from its storage compartment on the side of the coach.
2. Remove the cap from the RV drain and connect the drain hose to it.
3. Attach the other end of the flexible drain line to the dump station inlet. Be sure both ends of the flexible drain line are securely attached.
4. Drain the black water tank first, by pulling the termination valve handle toward you. Be sure to allow sufficient time for the tank to completely drain, then rinse the tank with several gallons of water by depressing the stool pedal or hand flush handle. Close the valve on the stool and let it fill before releasing to the tank. This creates additional force to flush the tank more completely.
5. Drain the gray water tank by pulling the termination valve handle toward you. Draining the gray tank last uses the soapy water in the tank to rinse the drain and flexible hose.
6. When tanks are emptied, close termination valves by pushing handles back to closed positions.
7. Remove flexible drain hose and wash it thoroughly with clean water. Remove the other end from the dump station inlet and replace it in its storage compartment. Secure the sewer hose storage cover, and replace the caps on both the recreational vehicle outlet and the dump station inlet.

Follow these guidelines to help ensure trouble-free operation:



- Never put anything in black water tank other than biodegradable RV toilet paper.
- Do not put automotive antifreeze, household toilet cleaners or drain cleaners, or any solid material into the waste water system.



- Always use chemicals in the black water system that are made especially for this purpose.
- When cleaning components of the waste water system, use cleaners made for RV systems.
- Always keep the drain cap in place and termination valves closed.



- After every third time the holding tanks are emptied, fill and flush both tanks with clean, fresh water a couple of times to keep them clear and clean.

NOTE: KEEPING THE BLACK WATER TANK CLEAN ALLOWS THE MONITOR PANEL TO ACCURATELY ASSESS THE STATUS OF THE TANK. ALWAYS REMEMBER TO CLEAN UP THE DUMP SITE BEFORE LEAVING. NEVER EMPTY YOUR HOLDING TANKS DIRECTLY ON THE GROUND, OR INTO A RIVER OR STREAM. DO NOT POLLUTE!

NOTES:
