



# SHOWERMISER OPERATION

## SHOWERMISER BENEFITS


The Showermiser directs water back into the unit's fresh tank while waiting for hot water to reach the shower. This water would normally go down the drain, into the gray holding tank. When hot water reaches the shower from the water heater, switching the Showermiser lever will direct the water to the shower faucets for normal use.

## SHOWERMISER DETAILS

**OFF POSITION:** In the *off* position, the shower will function as normal. Water will be directed to the shower faucets for normal use. Depending on the model, the lever will always be **up** or **down** in the *off* position.

**ON POSITION:** In the *on* position, water is directed back to the fresh tank instead of the shower faucets. The *on* position should only be used while waiting for hot water to arrive from the water heater. At no other time should the *on* position be used. Depending on the model, the lever will always be pointed **in** or **out** in the *on* position.

**COLOR CHANGING INDICATOR:** Next to the lever is a color changing indicator that will change from blue to white when hot water arrives.



## DIRECTIONS FOR USE

1. Turn on the hot water faucet in the shower and turn the Showermiser lever to the *on* position. Until hot water arrives, water will go back to the fresh tank.
2. When the color changing indicator turns white, switch the lever to the *off* position and find the desired water temperature by adjusting the hot and cold faucets.

**Note:** While using a city water connection, when the Showermiser is in the *on* position, water will begin to fill the fresh water tank. This can be drained from the tank or used later when city water is not available. Failure to turn the Showermiser to the *off* position can overflow the fresh water tank.

**Note:** The Showermiser should only be in the *on* position when using the shower and waiting for hot water to arrive. The Showermiser should never be left in the *on* position. After each use of the shower, check to make sure the Showermiser is *off*.